

DOBLO'




USER MANUAL MULTIMEDIAL SYSTEM

TIPS, CONTROLS AND GENERAL INFORMATION

ROAD SAFETY

Learn how to use the various system functions before setting off. Read the instructions for the system carefully before setting off.

WARNING	
	It can be dangerous if the volume is too high. Adjust the volume so it can still be heard background noises (e.g. horns, ambulances, police vehicles, etc.)

RECEPTION CONDITIONS

Reception conditions change constantly while driving. Reception may be interfered by the presence of mountains, buildings or bridges, or when you are far away from the broadcaster.

IMPORTANT The volume may be increased when receiving traffic alerts and news.

CARE AND MAINTENANCE

Observe the following precautions to ensure the system is fully operational:

- the display is sensitive to scratching, liquids and detergents. The display should not come in contact with pointed or rigid objects which could damage its surface. Do not press on the display when cleaning it.
- prevent any liquid from entering the system: this could be damaged beyond repair.

Only clean the front panel and the display with a soft, clean, dry, anti-static cloth. Cleaning and polishing products may damage the surface. Do not use alcohol or similar products to clean the panel or the display and ensure that the system is in OFF mode during cleaning operations.

MULTIMEDIA DEVICES: SUPPORTED AUDIO FILES AND FORMATS

For memory stick (USB) and portable media players (iPod) sources the system can play files with the following extensions and formats:

- .MP3 (8 – 320Kbps);
- .WAV;
- .WMA (8 – 320Kbps);
- .AAC;

For all sources (USB, iPod and Bluetooth®), the system can also play the following Playlist formats:

- .M3U
- .PLS
- .WPL


For USB sources the system can play videos with the following extensions and formats:

- .MP4;
- .DAT;
- .AVI

Video Codec Name	Profile	Level	Limitation
MPEG4	Simple Profile	L5	For Advanced Simple profile, only one point GMC is supported.
	Advanced Simple Profile		
H264	Baseline profile	L 4.1	For Baseline profile with SGM, the width limitation is 1280.
	Main profile		For Baseline profile without SGM, the width limitation is 4096.
	High profile		

For USB sources, the system can view images with the following extensions and formats:

- .JPEG;
- .JPG;

WARNING	
	<p>ALWAYS drive safely with your hands on the steering wheel. You have fully responsibility and assume all risks related to the use of the multimedia system features in this vehicle. Only use multimedia system when it is safe to do so. Failure to do so may result in an accident involving serious injury or death.</p>

The system supports FAT16, FAT32, ex FAT formatted USB devices. The system does not support devices with a capacity higher than 128 Gb and Hard Disk.





FRONT PANEL CONTROLS

STANDARD MODEL





NAVIGATION MODEL



Button	Function	Description
	Switching On/Off, Volume Adjustment & Back to Main Menu	Press the button to turn on the device, press and hold for 2 seconds to turn it off. Increase or decrease the volume via turning the knob left or right respectively. Press the button to go back to main menu in any selected menu.
RADIO	Radio	Press the button to enter radio source / Select radio band
MEDIA	Media Source	Press the button to enter/Select USB/iPod/BT media Sources. If Apple CarPlay or Android Auto Connection is active, Android Auto or Apple CarPlay media menu can be accessible.
PHONE	Phone	Press the button to enter the mobile phone menu. Further details are given in next chapters.
 or NAV	Display On/Off or Navigation	Press the button to turn the display on or off. or Press the button to turn the navigation system.
	Enter/Browse & Tune/Scroll	Press the button to enter the selected menu or approve a pop-up. Rotate the knob for manual seek for radio and change the selection up & down in browse.
	USB/iPod Port	Connect the device to USB connection port to activate iPod/CarPlay/Android Auto port.

STEERING WHEEL CONTROLS



Button	Function	Description
	Mute Button	Press the button for the activation/deactivation of the volume. To cut off the microphone device during BT (Bluetooth®) call, press the button to activate mute function. This allows to hear the interlocutor but not being heard from it. Press the mute button again to deactivate the function.
	Voice Command Button	Press to activate Android Auto and Apple Car Play voice command
	Call Accept Button	Press to pick-up incoming calls
	Call End Button	Press to end the call, or for refusing an incoming call.
	Search Button	Press the button to auto seek for next or previous radio station/track for media sources. Long press to change them faster.
	Volume Up/Down Button	Press to increase/decrease the volume. Long press to increase/decrease volume faster

TURNING ON/OFF THE RADIO

Press button briefly to turn on the device, press it for 2 or more seconds to turn it off. Rotate the button clockwise to increase the volume, or anti clockwise to decrease the volume.

RADIO MODE






Press the RADIO button on the touchscreen bottom left corner or icon in the Home page, to enter the Radio Menu.



Radio Mode Selection

In radio main screen, press RADIO button on the front panel or “FM/AM, AM/DAB (if available), DAB (if available)/FM” to switch to the bands AM, FM and DAB (if available). Each tuning mode can have a specific preselection set.

Radio Station Selection

In radio main screen turn  button/knob or press  and  button on screen to search for the desired radio station. Long press the  button on the touchscreen for rapid skip the radio frequencies. Long press the  button for rapid come back to the previous radio frequencies.

Displayed Information


After the desired radio station is selected on the display, the following information is shown:

At the top: the list of radio stations stored (preset) is displayed; the station being listened to is highlighted only if it is among the ones stored in the preset.




In the middle: the name of the radio station being listened to and the buttons to select the previous or the next radio station are displayed.


At the bottom: the following buttons are displayed:

- "FM/AM/DAB (if available) ": selection of the desired frequency band (button reconfigurable according to the band selected: AM, FM, DAB (if available));
- "Stations": list of the available radio stations.
- "Info": additional information on the source playing.
- "Audio": access to the "Audio setting" screen.





AM/FM/DAB (if available) Radio Station Tuning


Press the  icon to enter Direct Tune menu. The graphic keyboard on the display is used to enter the frequency of the station. In this mode, use buttons + and – to fine-tune the frequency. Press  button to delete a wrong number (and enter the correct station frequency). Press  button or the RADIO button on the display to return to the system main screen.



Fast searching of next/previous radio broadcasting

Keep pressing on  or  buttons to start fast searching. When you stop pressing the button, the audio will find the first listenable broadcast.

FM broadcasting list

To see all FM stations list, you need to press  button.


Presetting a Station (Preselection)

Pre-selections are activated by touching one of the preselection buttons located at the top of the display. To store the current radio station, press and hold down the button corresponding to the desired preset until a confirmation acoustic signal is heard. The system can store up to 12 radio station in each mode: 4 radio stations are displayed at the top.

DAB (if available) broadcasting

DAB (if available) third-generation broadcasting -- digital audio broadcasting, which provides sound quality close to CD, radio broadcasting and additional data services with unlimited work opportunities, it has the advantage of a transmission without noise, without interference and antiradio, adapted to the mobile reception of high velocity.

Press the "Browse" button to select "All stations" "Genres" "Ensembles".



All stations

Press "all stations", to see all the DAB (if available) broadcasts.


Genres

Press "Genres", to choose various types of DAB (if available) radio programs, such as weather, finance, children, religion, etc.


Ensembles

Press "Ensembles", to scroll through the DAB (if available) ensembles groups

MEDIA MODE

Press MEDIA button located on the faceplate or press the  icons on the home page to activate media sources. After source selection is completed, sound/photo files in the source are played automatically.

To play audio/photo files via USB, the corresponding device must be connected to the USB port on the radio, if needed via a required cable (only in the case of device other than USB stick). When a USB / iPod device is plugged in while the system is on, tracks stored on USB/iPod are available to play. Supported USB flash disks list is provided at the following link: <http://www.fiatnavigation.com>



WARNING

When connecting a device (USB or iPod) to the USB port, make sure that the handbrake lever is not obstructed.

If the mobile phone supports Bluetooth® connection, the audio files stored on the mobile phone can be listened via the radio in the car.

Seek Previous/Next

Press button to play the next selection. (this can be track/picture). Press button to return to the beginning of the selection or the beginning of the previous selection.

Fast Seek Previous/Next

Press and hold button on the touchscreen to fast forward the selected track. To fast rewind the track, press and hold the button.

Browse

This function is used to select tracks in the directory of active device. Additional options for the selection may vary depending on the connected device or the type of device connected. For example, if a USB / iPod device is connected, it can be navigated between artists, music genres, and albums, depending on the information in the songs.

In order to activate this function on corresponding device press the “Browse” button on the display, which allows the user to scroll through files and make a search. This button may not be available for some specific Apple®


devices. Press button to cancel browse function and turn to the precedent menu.

Use the "ABC" button inside each list to skip to the desired letter inside the list.


Song Information




Press “Info” button to display the information of the current track. Press “CLOSE” button to go back to the previous screen

Shuffle

Press  button to play the tracks in a random order. Press again to deactivate this function. Shuffle function can be available only if the USB or Bluetooth® device supports this function.

Repeat Song

Press  button repeatedly to cycle between Repeat One, Repeat All and Repeat OFF in loop. Repeat function can be available if the USB or Bluetooth® device support this function.

- Repeat One  ; in this mode the system repeatedly plays the current track.
- Repeat All  ; in this mode the system repeatedly plays the list of the current tracks.
- Repeat OFF  ; in this mode the tracks cycling is deactivated.

Media Mode

To activate media mode:

- 1) Put in the USB port a USB device or an Apple/Android device by USB cable.
- 2) Press the MEDIA button on the touch screen of the radio.

To play an audio track select the icons of the possible options: USB device, Ipod device, Android device (MTP).

Note: if the Autoplay setting is ON status. The radio will start to reproduce the audio tracks automatically.

WARNING



Be carefull when the USB/Ipod device is put in the USB port in order to avoid any damages.

BLUETOOTH® MODE

In order to active Bluetooth mode or Bluetooth streaming audio (BTSA), pair a Bluetooth device Before proceeding, the Bluetooth® device must be paired to the Multimedia System.

NOTE: See the pairing procedure in the Phone Mode section for more details.

To access Bluetooth® mode, press the “Source” button under the Media Menu of the Home Page, and then select “Bluetooth® Audio”.



PHONE MODE

Activating Phone Mode



Press PHONE button on the front panel or the  button on the main screen to activate phone mode.

Key Features:

- Dialing the number of the person wanted to be called.
- Contacts on the phone book of the cell phone can be viewed and called.
- Contacts on the recent calls can be viewed and called
- Up to 5 cell phones/digital players can be stored for easier and faster access.
- The calls on the radio device can be transferred to cell phone and the call on the mobile transferred to the device. Microphone device can be disabled.
- Sound files that are stored on mobile phone, can be played over radio device.



Sound of the mobile phone is directed to the car speaker system over radio. System interrupts radio sound automatically while mobile phone function is in use.


Pairing the Mobile Phone over BT



The instructions below are to be followed for registering procedure:

- Ensure that the vehicle is stationary; the pairing process between vehicle and mobile phone can happen only when the vehicle is stationary.
- Ensure Apple CarPlay/Android Auto is not active on the phone.

- Activate Bluetooth® function of the mobile phone.
- Press PHONE button of the radio in front panel .
- Press  Phones Button.
- Press the  button to start the pairing process.
- Search for “FIAT_XXXX” on mobile phone .
- If the pairing process doesn't go automatically enter the PIN code that is displayed on the screen of the radio, using the mobile phone, after mobile phone requires it. Otherwise confirm the code that is displayed on mobile phone..
- An Information screen which contains cell phone details is displayed when the pairing is completed.



WARNING



If the pairing process is interrupted or fails, it is recommended to delete the names of the two corresponding devices from the list of paired phones / devices from the phone and radio and repeat the procedure again from the starting point."

After updating the mobile phone's software, it is recommended to remove the phone from the radio-connected devices list, delete the previous connection of the phone from the Bluetooth® list, and pair the mobile phone again to assure the system works correctly.

WARNING



Apple phones set the Bluetooth® volume to the half of maximum for the first pairing. If the phone volume is low, change the Phone volume level in the Settings/Audio/Volume menu.


WARNING



Bluetooth® Connection Functions and sound quality may vary and depends on Mobile Phone Brand.
Supported mobile phones list is given at web <http://www.fiatnavigation.com>

Transfer of the Phone Data (Phonebook and Recent Calls)

If your mobile phone has a function for sending the phonebook via Bluetooth® technology, during the pairing procedure a pop-up screen will appear with the following request. Answer "Yes" to copy the whole phonebook and the list of recent calls to the system. Answer "No" to carry out the operation later.






After the first phone data transmission, the procedure for transmitting and updating the phonebook (if supported) starts as soon as a Bluetooth® connection is established between mobile phone and system.

This downloaded phonebook cannot be edited on the multimedia system. It can only be edited on the mobile phone. When the device is deleted from the paired device list or the restore default settings option is activated, the phonebook will be automatically deleted from the multimedia system. The changes are transferred and updated to the multimedia system on the next phone connection.




Whenever a mobile phone is connected to the system, a maximum of 3000 contacts can be downloaded and updated for each phone. Depending on the number of items downloaded from the phonebook, a slight delay can occur before the last downloaded entry can be used. Up to then the phonebook downloaded previously (if present) will be available. Only the phonebook of the mobile phone currently connected to the system can be accessed.

Connecting To a Particular Mobile Phone Or Audio Device After Pairing

Multimedia System will automatically connect to the highest priority paired phone and/or Audio Device within range. If you need to choose a particular phone or Audio Device follow these steps:


- Ensure that the Bluetooth® function is in ON status on the mobile phone
- Press the PHONE button.
- Press  **Telefoni** to enter to the list of paired devices.
- If the mobile phone is in use as a Media source, press  button on the touchscreen.
- If the mobile phone is in use only for Phone function, press  button on the touchscreen.
- If the mobile phone is in use as both Media source and Phone, press "Connect Both" button on the touchscreen.
- A pop-up will appear, and multimedia system connects to the mobile phone automatically.


Disconnecting A Phone Or Audio Device

- Press the PHONE button on the front panel.
- Press the  **Telefoni** button on the display.
- Select the specific device from the "Paired Devices List".
- Press  button to disconnect as "Media source" and/or press  button to disconnect as "Phone source".

Deleting A Phone or Audio Device

To delete a mobile phone or Bluetooth® audio device from a list, proceed as follows:

- Press the PHONE button on the front panel.
- Select  button on the display.
- Select the specific device from the "Paired Devices List".
- Press the "Delete" button
- A confirmation screen will appear on the display: press "Yes" to delete the device or "No" to cancel the operation.



PHONE CALL FEATURES

The following features can be accessed through the Multimedia system if the feature(s) are available and supported by Bluetooth® on your mobile service plan. For example, if your mobile service plan provides three-way calling, this feature can be accessed through the Multimedia system. Check with your mobile service provider for the features that you have.

Ways To Initiate A Phone Call

A call can be made by:

- Pressing "Contacts" button (mobile phone phonebook);
- Pressing "Recent Calls" button;
- Pressing "Keypad" button;
- Pressing the "Call Back" button.


Making a Phone Call

The operations described below can only be accessed if supported by the mobile phone in use. For all functions available, refer to the mobile phone owner's handbook.



Dialing the phone number using the "keypad" button

Enter the phone number using the graphic keyboard displayed. Proceed as follows:

- Press the  button on the touchscreen in Phone Main Menu;
- Use the numbered buttons to enter the number;
- Press the "Call" button to make a call.

Dialing the phone number using the mobile phone


It is possible to dial a phone number with the mobile phone and continue using the system (never allow yourself to be distracted while driving). When a phone number is dialed with the keyboard of the mobile phone, the audio of the call is played over your car's sound system.

Recent calls


The list of the last calls made for each of the following call types can be displayed:

- Incoming calls;
- Outgoing calls;
- Missed calls
- All calls

To access these types of calls, press the "Recent Calls" button on the Phone menu main screen.




Managing an Incoming Call - Answering a phone call

When a phone call is received on the mobile phone, the system deactivates the audio system (if active) and displays a popup screen. Press the "Accept" button or the  button on the steering wheel controls to answer.

Press the "Reject" button or the  button on the steering wheel controls to reject.

Press the "Ignore" button to ignore the incoming call, the incoming call still exist in the background, if user press PHONE button of the front panel, the incoming call screen will appear again.



Answering an incoming call during an active conversation

To answer an incoming call while another phone conversation is in progress, press the "Hold" button to put the ongoing call on hold and answer the new incoming call.

Press "Reject" button to close the ongoing call and answer the new incoming call.

Press "Ignore" button to ignore the new incoming call and continue with the ongoing call.

IMPORTANT: Not all mobile phones may support the management of an incoming call when another phone conversation is active.


Making a second Phone Call

When a phone conversation is active, a second phone call can be made in 3 different ways on the same menu as follows:

Press "Add Call" button and Keypad screen is open;

- Dial the number using the numbered buttons and press "Call" button;
- Press "Recent Calls" button to select from the list of recent calls;
- Press "Contact" and go to the Phonebook then select the contact;






Managing two Phone Calls


If two calls are in progress (one active and one on hold), it is possible to switch between them pressing the "Switch" button or to merge the two calls in a conference pressing the "Join" button.

Note

Check whether the telephone in use supports the management of a second call and the "Conference" mode.



Ending a Call


Press the "End" button or the  button on the steering wheel controls to end a call in-progress. Only the ongoing call is ended and any call on hold becomes the new active call. Depending on the type of mobile phone, if the ongoing call is ended by the caller, the call on hold may not be activated automatically.

Redialing


To call the number/contact of the last call made, press the "Call Back" button on the Phone Main Menu.

Continuing a Phone Call

After the engine is switched off, if in the power off delay setting it is selected the 20 minutes option it is still possible to continue a phone call. The call continues until it is ended manually or for a maximum period of about 20 minutes. When the system is switched off the call is transferred to the mobile phone.



Activation/Deactivation of the Microphone

During a call the microphone can be deactivated pressing the "Mute" button on the touchscreen (or on the steering wheel controls ). When the microphone is deactivated it is still possible to listen to the call in progress. To reactivate the microphone, press the corresponding button again.

Transferring a Call

The ongoing calls can be transferred from the mobile phone to the system and vice versa without ending the calls. To transfer the call, press the "Privacy" button.

Apple CarPlay and Android Auto

The Apple CarPlay and Android Auto applications allow you to use your smartphone in the car safely and intuitively. To enable them, just connect a compatible smartphone via the USB port and the phone's contents will be automatically shown on the system display. To check the compatibility of your

smartphone, see the indications on the websites: <https://www.android.com/auto/> for Android Auto and <https://www.apple.com/tr/ios/carplay/> for CarPlay.

If the smartphone is connected correctly to the car via the USB port, the Apple CarPlay or Android Auto icon will be displayed the main menu.

WARNING!

When Apple Car play/Android Auto apps are enabled by the user, the scrolling function via rotary knob is not available.

Android Auto APP Setup

Before use, download the Android Auto application to your smartphone from Google Play Store. The application is compatible with Android 5.0 (Lollipop) and later versions. To use Android Auto, the smartphone must be connected to the car with a USB cable. On the first connection, you will have to perform the setup procedure that appears on the smartphone. You can only perform this procedure with the vehicle stationary. Once connected to the USB port, the Android Auto application establishes a parallel Bluetooth® connection.

WARNING!


If you installed and uninstalled "Android Auto" application on the phone; when connecting the mobile phone by USB to the radio, it is possible that appears the "Android Auto" pop up on the radio. To listen the music inside the phone it is necessary to disconnect and reconnect again the USB connector on the radio.

Apple CarPlay APP Setup

Apple CarPlay is compatible with the iPhone 5 or more recent models, with the iOS 7.1 operating system or latter versions. Before using Apple CarPlay, enable Siri from "Settings" General Siri on the smartphone. To use Apple CarPlay, the smartphone must be connected to the car with a USB cable.


Note:

- Enabling Apple CarPlay/Android Auto or some functions could require interaction on the smartphone. If necessary, complete the step on your device (smartphone).

WARNING	
	Apple phones set the Bluetooth® volume to the half of maximum for the first pairing. If the phone volume is low, change the BT level on the radio in Equalizer settings menu, or change the BT level on the mobile phone.

Interaction

After the setup procedure, when connecting your smartphone to the car's USB port, the application will run automatically on the system.

You can interact with Apple CarPlay and Android Auto by long pressing on  button on the steering wheel, using the BROWSE/ ENTER button/knob (to select and confirm) or using the system touchscreen.

Navigation


With the Apple CarPlay and Android Auto applications, the driver can use the navigation system on their smartphone.

Notes:

- Bluetooth® is disabled while Apple CarPlay is being used
- Bluetooth® remains on while Android Auto is being used
- The data connection will depend on the payment plan of the smartphone
- The information may be subject to changes that depend on the operating system of the smartphone.


Exiting the Android Auto and Apple CarPlay apps

With Apple CarPlay app enabled, you can still access the contents of the system by using the controls available (Press

 button) and icons shown on the display. To return to the system contents with the Android Auto app enabled select the last item on the Android Auto system bar and select "Back to Fiat". To end the Apple CarPlay or

Android Auto session, physically disconnect the smartphone from the car's USB port.

APP navigation (if available) settings



Align to the navigation applications, the driver can use the navigation system to plan and navigate. For more details on how to use this application, refer to the navigator user manual.


WARNING




When the navigation system is activated is not possible to scroll the lists by the rotary.


RVC (if available)

Align in reverse gear (R) and your display will automatically show the rear of your car. RVC will be shown when the radio is in stand by.



Settings

Press  button to enter the Settings menu. The menu includes the following items:



Audio

Audio related settings are located under this function. (Touch sound, Loudness, Equalizer, Balance & Fader, Volume, Speed Volume Control)





Touch Sound


Press the relevant button to activate/deactivate the acoustic signal when the buttons on the display are pressed.

Loudness







To activate/deactivate the "Loudness" function to improve the sound quality at low volumes.



Equalizer

Select "Equalizer" on the display to adjust the bass, middle and treble tones. Use the "+" or "-" buttons to carry out the settings desired. Tapping on the bass middle or treble bar also is possible to change the value. Then press  button to return to the "Audio" menu. Press  button to cancel and exit this screen.



Balance and Fader


Press the "Balance/Fader" button to balance the sound from the front and rear seat speakers. Press the  or  buttons (only if the rear speakers are available) to balance the front and rear speakers. Press the  or  buttons to balance the speakers on the left and the right side. The adjustment is also possible by moving the white point on the right side of the display upwards/downwards/to the left/to the right. Press the central "C" button to balance the adjustments. Then press  button to return to the "Audio" menu. Press  button to cancel and exit this screen.




Volume

Press the “Volume” button to enter into the volume settings interface and to adjust the volume of multimedia (music and radio), phone, ringtone and speech.

WARNING





If the user sets the volume level below 5 or greater than 25, on the next boot up these values will not be stored in the memory, and the radio will boot up with volume at level 5 (if the level was less than 5 when the radio was switched off) or at level 25 (if the level was greater than 25 when the radio was switched off)



Speed Volume Control

"Off" and "1, 2 or 3".


The option selected is displayed. Choose "1, 2 or 3" to increase the volume proportionally to vehicle speed.

Then press  button to return to the "Audio" menu. Press  button to cancel and exit this screen.



Radio

Alternative Frequency and Traffic Announcement functions can be activated/deactivated under Radio settings.



AF Setting

Press the “AF Setting” button for activation/deactivation of the automatic tuning of the strongest signal for the currently broadcasted station.

TA Setting

Press the “TA Setting” button for activation/deactivation of the automatic tuning of the traffic announcements.

DAB (if available) Announcements

Press the "DAB (if available) announcements" button to select different announcement types, such as news flash, weather flash, sports report, etc.

Regional


Press the “ON / OFF” buttons for activation/deactivation of the Regional function.

Language

Set the language by selecting any possible language from the list.

General

Luminance, AutoPlay, Power Off Delay functions can be activated/deactivated under General setting menu.



Luminance

Press the "Luminance" button to set the display brightness according to "Day", "Night" condition.

AutoPlay

AutoPlay is a feature of the multimedia system that automatically begins playing music of the USB device, as soon as it is connected. This feature can be turned on or off in this menu. Its default setting is on.

Power Off Delay

To keep the radio on for 20 minutes after the ignition key is turned to STOP.

Android Auto

Press ON button to be connected Android Auto and press OFF not to be connected Android Auto.

User Manual

Scan the QR code with a mobile device allows accessing the website from the mobile device. Please note that the function is unavailable while the vehicle is in motion.

<http://www.fiatnavigation.com>



Restore Settings

Reset the radio to the factory settings will erase all the settings previously defined by the user. Confirm to reset the device to the factory settings. Wait for a short time for the factory settings to be restored.

Notes:

Please read this manual thoroughly and keep this manual as a reference before the use of this device.

- For safe driving, do not look at the display continuously while driving.
- Do not allow liquids or solids to get into the device in order to avoid damage.
- Consult your authorized workshop for repair and maintenance.
- Using the device for an extended period while the engine is not running may cause the battery to discharge.
- Do not touch the screen with hard or sharp objects, as this may cause damage to the screen.

Faults caused by misuse and the following conditions are not covered by the warranty:

- Faults due to external electrical components.
- Faults due to external sources (humidity, water, impact, fire, lightning, chemicals, dust).
- Use of non-genuine spare parts that are not approved by the manufacturer.
- Interventions to the device other than authorized service.
- Deleted or altered serial numbered devices.

RED Homologation information

български [Bulgarian]	С настоящото Daiichi Elektronik San. ve Tic. A.S. декларира, че този тип радиосъоръжение D7131AD е в съответствие с Директива 2014/53/ЕС. Цялостният текст на ЕС декларацията за съответствие може да се намери на следния интернет адрес: https://w w w .daiichi.com/about/	Lietuvių [Lithuanian]	Aš, Daiichi Elektronik San. ve Tic. A.S., patvirtinu, kad radijo įrenginių tipas D7131AD atitinka Direktyvą 2014/53/ES. Visas ES atitikties deklaracijos tekstas prieinamas šiuo interneto adresu: https://w w w .daiichi.com/about/
Cesky [Czech]	Tímto Daiichi Elektronik San. ve Tic. A.S. prohlašuje, že typ rádiového zařízení D7131AD je v souladu se směrnicí 2014/53/EU. Úplné znění EU prohlášení o shodě je k dispozici na této internetové adrese: https://w w w .daiichi.com/about/	Latviski [Latvian]	Ar šio Daiichi Elektronik San. ve Tic. A.S. deklarė, ka radiolėkarta D7131AD atbilst Direktivai 2014/53/ES. Plėnas ES atbilstības deklarācijas teksts ir pieejams šādā interneta vietnē: https://w w w .daiichi.com/about/
Deutsch [German]	Hiermit erklärt Daiichi Elektronik San. ve Tic. A.S., dass der Funkanlagentyp D7131AD der Richtlinie 2014/53/EU entspricht. Der vollständige Text der EU-Konformitätserklärung ist unter der folgenden Internetadresse verfügbar: https://w w w .daiichi.com/about/	Malti [Maltese]	B'dan, Daiichi Elektronik San. ve Tic. A.S., niddikjara li dan it-tip ta' tagħmir tar-radju D7131AD huwa konformi mad-Direttiva 2014/53/UE. It-test kollu tad-dikjarazzjoni ta' konformità tal-UE huwa disponibbli f'dan l-indirizz tal-Internet li ġej: https://w w w .daiichi.com/about/
Dansk [Danish]	Herved erklærer Daiichi Elektronik San. ve Tic. A.S., at radioudstyrstypen D7131AD er i overensstemmelse med direktiv 2014/53/EU. EU-overensstemmelseserklæringens fulde tekst kan findes på følgende internetadresse: https://w w w .daiichi.com/about/	Dutch [Netherlands]	Hierbij verklaar ik, Daiichi Elektronik San. ve Tic. A.S., dat het type radioapparatuur D7131AD conform is met Richtlijn 2014/53/EU. De volledige tekst van de EU-conformiteitsverklaring kan w orden geraadpleegd op het volgende internetadres: https://w w w .daiichi.com/about/
Eesti [Estonian]	Käesolevaga deklareerib Daiichi Elektronik San. ve Tic. A.S., et käesolev raadioseadme tüüp D7131AD vastab direktiivi 2014/53/EL nõuetele. ELi vastavusdeklaratsiooni täielik tekst on kättesaadav järgmisel internetiaadressil: https://w w w .daiichi.com/about/	Polski [Polish]	Daiichi Elektronik San. ve Tic. A.S. niniejszym oświadczam, że typ urządzenia radiowego D7131AD jest zgodny z dyrektywą 2014/53/UE. Pełny tekst deklaracji zgodności UE jest dostępny pod następującym adresem internetowym: https://w w w .daiichi.com/about/
Espanol [Spanish]	Por la presente, Daiichi Elektronik San. ve Tic. A.S. declara que el tipo de equipo radioeléctrico D7131AD es conforme con la Directiva 2014/53/UE. El texto completo de la declaración UE de conformidad está disponible en la dirección Internet siguiente: https://w w w .daiichi.com/about/	Portugues [Portuguese]	O(a) abaixo assinado(a) Daiichi Elektronik San. ve Tic. A.S. declara que o presente tipo de equipamento de rádio D7131AD está em conformidade com a Diretiva 2014/53/UE. O texto integral da declaração de conformidade está disponível no seguinte endereço de Internet: https://w w w .daiichi.com/about/
Suomi [Finnish]	Daiichi Elektronik San. ve Tic. A.S. vakuuttaa, että radiolaitetyypin D7131AD on direktiivin 2014/53/EU mukainen. EU-vaatimustenmukaisuusvakuutuksen täysimittainen teksti on saatavilla seuraavassa internetosoitteessa: https://w w w .daiichi.com/about/	Românesc [Romanian]	Prin prezenta, Daiichi Elektronik San. ve Tic. A.S. declară că tipul de echipamente radio D7131AD este în conformitate cu Directiva 2014/53/UE. Textul integral al declarației UE de conformitate este disponibil la următoarea adresă internet: https://w w w .daiichi.com/about/
Francais [French]	Le soussigné, Daiichi Elektronik San. ve Tic. A.S., déclare que l'équipement radioélectrique du type D7131AD est conforme à la directive 2014/53/UE. Le texte complet de la déclaration UE de conformité est disponible à l'adresse internet suivante: https://w w w .daiichi.com/about/	Swenska [Swedish]	Härmed försäkrar Daiichi Elektronik San. ve Tic. A.S. att denna typ av radioutrustning D7131AD överensstämmer med direktiv 2014/53/EU. Den fullständiga texten till EU-försäkran om överensstämmelse finns på följande webbadress: https://w w w .daiichi.com/about/
English	Hereby, Daiichi Elektronik San. ve Tic. A.S. declares that the radio equipment type D7131AD is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: https://w w w .daiichi.com/about/	Slovensko [Slovenian]	Daiichi Elektronik San. ve Tic. A.S. potrjuje, da je tip radijske opreme D7131AD skladen z Direktivo 2014/53/EU. Celotno besedilo izjave EU o skladnosti je na voljo na naslednjem spletnem naslovu: https://w w w .daiichi.com/about/
ελληνικά [Greek]	Με την παρούσα ο/η Daiichi Elektronik San. ve Tic. A.S., δηλώνει ότι ο ραδιοεξοπλισμός D7131AD π πληροί την οδηγία 2014/53/ΕΕ. Το π πλήρες κείμενο της δηλώσης συμμόρφωσης ΕΕ διατίθεται στην ακόλουθη ιστοσελίδα στο διαδίκτυο: https://w w w .daiichi.com/about/	Slovensky [Slovak]	Daiichi Elektronik San. ve Tic. A.S. týmto vyhlasuje, že rádiové zariadenie typu D7131AD je v súlade so smernicou 2014/53/EÚ. Úplné EÚ vyhlásenie o zhode je k dispozícii na tejto internetovej adrese: https://w w w .daiichi.com/about/
Hrvatski [Croatian]	Daiichi Elektronik San. ve Tic. A.S. ovdje izjavljuje da je radijska oprema tipa D7131AD u skladu s Direktivom 2014/53/EU. Cjeloviti tekst EU izjave o sukladnosti dostupan je na sljedećoj internetskoj adresi: https://w w w .daiichi.com/about/	Norsk [Norwegian]	Herved Daiichi Elektronik San. ve Tic. A.S. erklærer at radioutstyr typen D7131AD er i samsvar med direktiv 2014/53 / EU. Den fullstendige teksten i EU-erklæring er tilgjengelig på følgende internetadresse : https://w w w .daiichi.com/about/
Magyar [Hungarian]	Daiichi Elektronik San. ve Tic. A.S. igazolja, hogy a D7131AD típusú rádióberendezés megfelel a 2014/53/EU irányelvnek. Az EU-megfelelőségi nyilatkozat teljes szövege elérhető a következő internetes címen: https://w w w .daiichi.com/about/	Islenska [Icelandic]	Hér, Daiichi Elektronik San. ve Tic. A.S. lýsir yfir að radióbúnaður gerð D7131AD er í samræmi við tilskipun 2014/53 / ESB. The fullur texti af ESB-samræmisýrirlýsing er í boði á eftirfarandi veffangi: https://w w w .daiichi.com/about/
Italiano [Italian]	Con la presente, Daiichi Elektronik San. ve Tic. A.S., dichiara che il tipo di apparecchiatura radio D7131AD è conforme alla direttiva 2014/53/UE. Il testo completo della dichiarazione di conformità UE è disponibile al seguente indirizzo Internet: https://w w w .daiichi.com/about/	Türkçe [Turkish]	İşbu belge ile Daiichi Elektronik San. Ve Tic. Glbl. D7131AD tipi radyo ekipmanının 2014/53 / AB sayılı Direktife uygun olduğunu beyan eder. AB uygunluk beyanının tam metni aşağıdaki internet adresinden edinilebilir: https://w w w .daiichi.com/about/
Русский язык [Russian]	Настоящим Daiichi Elektronik San. ve tic. KAK. заявляет, что радиоборудование типа D7131AD соответствует директиве 2014/53 / EU. Полный текст декларации о соответствии ЕС доступен по следующему интернет-адресу: https://w w w .daiichi.com/about/	Українська мова [Ukrainian]	Цим, Daiichi Elektronik San. ve Tic. A.S. заявляє, що радіобладнання типу D7131AD відповідає Директиві 2014/53 / ЄС. Повний текст декларації про відповідність ЄС можна знайти на наступній інтернет-сторінці: https://w w w .daiichi.com/about/

